



AIR SPRING & SHOCK ABSORBER SUSPENSION REFERENCE CHART

SUSPENSION	AIR SPRING OE#	AIR SPRING PDC#	SHOCK OE#	SHOCK PDC#
NEWAY/HOLLAND				
NS190-16	905-57-223	FS8204	900-44-162	NW900-44-162
NS190-16.5	905-57-225	FS9366	900-45-040	NW900-45-040
NS190-17	905-57-225	FS9366	900-45-040	NW900-45-040
NS190-18	905-57-159	FS9365	900-45-054	NW900-45-054
AR90-1-12 LH	905-57-131	FS9463	900-44-162	NW900-44-162
AR90-1-12 RH	905-57-130	FS9463	900-44-162	NW900-44-162
AR90-1-14	905-57-113	FS9362	900-44-162	NW900-44-162
AR90-1-15	905-57-124	FS9304	900-44-448	NW900-44-448
AR90-1-16	905-57-124	FS9304	900-44-448	NW900-44-448
AR90-1-17	905-57-113	FS9362	900-44-162	NW900-44-162
RL196-12	905-57-127	FS9294	900-44-977	NW900-44-977
RL196-14	905-57-120	FS9293	900-44-978	NW900-44-978
RL196-15	905-57-121	FS9295	900-44-978	NW900-44-978
RL196-16	905-57-121	FS9295	900-44-979	NW900-44-979
RL196-17	905-57-122	FS9291	900-44-979	NW900-44-979
RL196A-12	905-57-173	FS8204	900-44-162	NW900-44-162
RL196A-13.5	905-57-159	FS9365	900-44-162	NW900-44-162
RL196A-14	905-57-120	FS9293	900-45-040	NW900-45-040
RL196A-15	905-57-121	FS9295	900-45-040	NW900-45-040
RL196A-16	905-57-121	FS9295	900-44-794	NW900-44-794
RL196A-17	905-57-139	FS9291	900-44-794	NW900-44-794
NS400-16	905-57-223	FS8204	900-45-298	NW900-45-298
NS400-16.5	905-57-225	FS9366	900-44-162	NW900-44-162
NS400-17	905-57-225	FS9366	900-45-299	NW900-45-299
NS400-18	905-57-194	FS8803	900-45-040	NW900-45-040
CB400-15.5	508-57-000	NW508-57-000	900-45-298	NW900-45-298
CB400-16	508-57-000	NW508-57-000	900-45-298	NW900-45-298
CB400-16.5	508-57-000	NW508-57-000	900-44-162	NW900-44-162
CB400-17	508-57-000	NW508-57-000	900-44-162	NW900-44-162
CB400-18	508-57-000	NW508-57-000	900-45-040	NW900-45-040

**CB400/4000 Series 15.5 - 17 require use of spacer under air spring.
Refer to SAFHolland Doc# XL-AR368 at www.safholland.us**



AIR SPRING & SHOCK ABSORBER SUSPENSION REFERENCE CHART

SUSPENSION	AIR SPRING OE#	AIR SPRING PDC#	SHOCK OE#	SHOCK PDC#
NEWAY/HOLLAND (Cont.)				
GURL250-14	905-57-167	FS8748	SPECIAL ORDER	SPECIAL ORDER
RLU228-9-3 FURNITURE	905-57-117	FS9921	900-45-054	NW900-45-054
RLU228-6-3 DROP DECK	905-57-117	FS9921	900-44-162	NW900-44-162
AR92-US-8 FLATBED	905-57-117	FS9921	<i>SPECIAL ORDER</i>	<i>SPECIAL ORDER</i>
RLU228-6.75 FEDEX GRND	905-57-223	FS8204	900-45-040	NW900-45-040
SA226-16	905-57-121	FS9295	900-45-083	NW900-45-083
RLU228-10-4 DROP DECK	905-57-119	FS9922	900-45-040	NW900-45-040
REYCO				
86AR/RS1015 , 14-17	20018-01	FS7555	18165-01	GF85006
86AR/RS1035, 14-17	20018-01	FS7555	18165-01	GF85006
19AR/RS1062, 14-15	20018-01	FS7555	700098-01	<i>SPECIAL ORDER</i>
19AR/RS1062, 16-17	20018-01	FS7555	24392-01	<i>SPECIAL ORDER</i>
20AR/RS1062	20018-01	FS7555	700098-03	<i>SPECIAL ORDER</i>
HENDRICKSON/HT				
HT190-14	S-20010	HTS-20010	S-20001	HTS-20001
HT190-15	S-20010	HTS-20010	S-20001	HTS-20001
HT190-16	S-20010	HTS-20010	S-20001	HTS-20001
HT190-17	S-20010	HTS-20010	S-20001	HTS-20001
HK-KFRAME 14-17	S-22045	FS8755	S-21292	HTS-21292
HT190UB7-021	S-20217	HTS-20217	S-23649	HTS-23649
HT230-14	S-20010	HTS-20010	S-20002	HTS-20002
HT230-15	S-20010	HTS-20010	S-20002	HTS-20002
HT230-16	S-20010	HTS-20010	S-20002	HTS-20002
HT230-17	S-20010	HTS-20010	S-20002	HTS-20002
HT250U-9.2 FLATBED	S-13122	HTS-13122	<i>SPECIAL ORDER</i>	<i>SPECIAL ORDER</i>
MERITOR				
RHP11	A2258F1410	RWA-2258-F-1410	85919	GF85919
DANA				
ROADRANGER	SR1JA100	DNSR1VA105	SR1JA102	HTS-29895